



- A=1,5      1=8,5
- B=19,7     2=19,3
- C=14        3=11
- D=19,7     4=5
- E=1,5       5=9,5
- G=1,5       6=5
- H=2,5       7=7
- 8=6,3

All sizes are in Centimeters.

Except:

Button holes are 30 millimeter.

Joystick hole is 24 millimeter

Outside button diameter is 36 millimeter

Total outside dimintions=  
56,8 X 16,9 Cm.

